

**CORRESPONDANCE VIBRATEURS
PNEUMATIQUES**
ANCIENNE VERSION ->
NOUVELLE VERSION

NCB		K
NCB 1	➔	K 8
NCB 2		K 10
NCB 3		K 13
NCB 5		K 16
NCB 10		K 20
NCB 20		K 25
NCB 50		K 30
NCB 70		K 36

NTK AL Et NTK		FAL
NTK 18AL	➔	FAL18
NTK 25AL		FAL25
NTK 8AL		FAL8
NTK 40AL		FAL35
NTK 15X	➔	VTL 155
NTK 16		VTL 165
NTK 25		VTL 255
NTK 55		VTL 555

NTS		FP
NTS 120 HF	➔	FP 12 S
NTS 120 NF		FP 12 M
NTS 120 NF		FP 12 L
NTS 180 HF		FP 18 S
NTS 180 NF		FP 18 M
NTS 180 NF		FP 18 L
NTS 250 HF		FP 25 S
NTS 250 NF		FP 25 M
NTS 250 NF		FP 25 L
NTS 350 HF		FP 35 S
NTS 350 NF		FP 35 M
NTS 350 NF		FP 35 L

NCT		GT
NCT 1	➔	GT 4
NCT 2		GT 6
NCT 3		GT 8
NCT 4		GT 10
NCT 4i		GT 10 S
NCT 5		GT 13
NCT 10		GT 16
NCT 10i		GT 16 S
NCT 15		GT 20
NCT 29		GT 25
NCT 29i		GT 25 S
NCT 55		GT 30
NCT 108		GT 36
NCT 108i		GT 36 S
NCT 126		GT 40
NCT 250		GT 48
NCT 250i	GT 48 S	

NCR		DAR
NCR 3	➔	DAR 2
NCR 10		DAR 3
NCR 22		DAR 4
NCR 57		DAR 5
NCR 120		DAR 6

NTS .../...		VFP .../...
NTS 50/01	➔	VFP 50/01
NTS 50/04		VFP 50/04
NTS 50/10		VFP 50/10
NTS 50/20		VFP 50/20
NTS 54/02		VFP 54/02
NTS 75/01		VFP 75/01

PKL		PP
PKL 150 ou PKL 740/5	➔	PP 150
PKL 170 ou PKL 2100/5		PP 170
PKL 200		PP 200
Ou PKL plus petits - à voir		